| Original | | Replacement | |
|---|---|---|---|
| | Power Tuner | | Power |
| | Mute | | MUTE |
| | 1 Tuner | | 1 |
| | 2 Tuner | | 2 |
| | 3 Tuner | | 3 |
| | 4 Tuner | | 4 |
| | 5 Tuner | | 5 |
| | 6 Tuner | | 6 |
| | 7 Tuner | | 7 |
| | 8 Tuner | | 8 |
| | 9 Tuner | | 9 |
| | 0 Tuner | | 0 |
| | Cinema Go | | -/-- / EPG |
| | Vol + | | VOL + |
| | Vol - | | VOL - |
| | Play Tuner/Phono/Cable Box | | Play |
| | Stop Tuner/Phono/Cable Box | | Stop |

| Original | | Replacement | |
|---|---|---|---|
| | Loudness | | Subt. |
| | Subw. On/Off | | VOD |
| | Mode/Virtual | | OPT+ |
| | Night | | WIDE |
| | Surround On/Off | | MEDIA |
| | Channel/Rear + | | CH + |
| | Channel/Rear - | | CH - |
| | Surround Mode | | TV/R |
| | Test Tone | | EXIT |
| | Sub woofer + | | Green (B) |
| | Sub Woofer - | | Red (A) |
| | Right Tuner | | RIGHT |
| | Up Tuner | | UP |
| | Down Tuner | | DOWN |
| | Left Tuner | | LEFT |
| | OK Tuner | | OK |
| | Menu / Guide Tuner | | MENU |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| NEWS/TA | i / News/ TA | INFO | I NFO | | |
| CHANNE | I < Channel / Track | | First | | |
| L/TRACK | Channel / Track >I Tuner | | Last | | |
| FR.D. | Pause/ FR. D. | | Pause | | |
| TUNER | Tuner | SHIFT + VOD | Shift + VOD | | |
| PHONO | Phono | SHIFT + MEDIA | Shift + MEDI A | | |
| | Power Phono | SHIFT + | Shift + Power | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power Tv | | Power |
| TV | TV | D | Blue (D) |
| MUTE | Mute Tv | | MUTE |
| 1 | 1 Tv | 1 | 1 |
| 2 | 2 Tv | 2 | 2 |
| 3 | 3 Tv | 3 | 3 |
| 4 | 4 Tv | 4 | 4 |
| 5 | 5 Tv | 5 | 5 |
| 6 | 6 Tv | 6 | 6 |
| 7 | 7 Tv | 7 | 7 |
| 8 | 8 Tv | 8 | 8 |
| 9 | 9 Tv | 9 | 9 |
| 0 | 0 Tv | 0 | 0 |
| GUIDE MENU | Menu/Guide Tv | MENU | MENU |
| OK | OK Tv | OK | OK |
| | Up Tv | ▲ | UP |
| | Down Tv | ▼ | DOWN |

| Original | | Replacement | |
|---|---|---|---|
| | Right Tv | ▶ | RIGHT |
| | Left Tv | ◀ | LEFT |
| + | Vol + Tv/CD | + VOL | VOL + |
| − | Vol - Tv/CD | VOL − | VOL - |
| ▶ | Play Tv | ▶ | Play |
| ■ | Stop Tv | ■ | Stop |
| i NEWS/TA | i/News/TA Tv | INFO | INFO |
| CHANNE | I< Channel/Track | ⏮ | First |
| L/TRACK | Channel/Track >I | ⏭ | Last |
| | Power CD | SHIFT + | Shift + Power |
| CD | CD | C | Yellow (C) |
| MUTE | Mute CD | SHIFT + | Shift + MUTE |
| 1 | 1 CD | SHIFT + 1 | Shift + 1 |
| 2 | 2 CD | SHIFT + 2 | Shift + 2 |
| 3 | 3 CD | SHIFT + 3 | Shift + 3 |
| 4 | 4 CD | SHIFT + 4 | Shift + 4 |
| 5 | 5 CD | SHIFT + 5 | Shift + 5 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 6 | 6 CD | SHIFT + 6 | Shift + 6 | | | | |
| 7 | 7 CD | SHIFT + 7 | Shift + 7 | | | | |
| 8 | 8 CD | SHIFT + 8 | Shift + 8 | | | | |
| 9 | 9 CD | SHIFT + 9 | Shift + 9 | | | | |
| 0 | 0 CD | SHIFT + 0 | Shift + 0 | | | | |
| | Up CD | SHIFT + ▲ | Shift + UP | | | | |
| | Down CD | SHIFT + ▼ | Shift + DOWN | | | | |
| | Right CD | SHIFT + ▶ | Shift + RIGHT | | | | |
| | Left CD | SHIFT + ◀ | Shift + LEFT | | | | |
| i NEWS/TA | i / News/TA CD | SHIFT + INFO | Shift + INFO | | | | |
| ■ | Stop CD | SHIFT + ■ | Shift + Stop | | | | |
| ▶ | Play CD | ❚❚ | Pause | | | | |
| CHANNE | I < CD | ◀◀ | Rewind | | | | |
| L/TRACK | >I CD | ▶▶ | Fast Forward | | | | |
| FR.D. | Pause/FR.D. CD | SHIFT + ❚❚ | Shift + Pause | | | | |
| CANCEL | : >/Cancel CD | EXIT | EXIT | | | | |
| DVD DISC | Disc/DVD CD | VOD | VOD | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power SAT | | Power |
| SAT | SAT | C | Yellow (C) |
| 1 | 1 SAT | 1 | 1 |
| 2 | 2 SAT | 2 | 2 |
| 3 | 3 SAT | 3 | 3 |
| 4 | 4 SAT | 4 | 4 |
| 5 | 5 SAT | 5 | 5 |
| 6 | 6 SAT | 6 | 6 |
| 7 | 7 SAT | 7 | 7 |
| 8 | 8 SAT | 8 | 8 |
| 9 | 9 SAT | 9 | 9 |
| 0 | 0 SAT | 0 | 0 |
| MUTE | Mute SAT | | MUTE |
| + | Vol + SAT/DVD | VOL + | VOL + |
| – | Vol - SAT/DVD | VOL – | VOL - |
| | Play SAT | | Play |
| | Stop SAT | | Stop |

| Original | | Replacement | |
|---|---|---|---|
| NEWS/TA | i/News/TA SAT | INFO | INFO |
| GUIDE MENU | Menu/Guide | MENU | MENU |
| OK | OK SAT | OK | OK |
| | Up SAT | ▲ | UP |
| | Down SAT | ▼ | DOWN |
| | Right SAT | ▶ | RIGHT |
| | Left SAT | ◀ | LEFT |
| CHANNE | I< Channel/Track SAT | | First |
| L/TRACK | Channel/Track >I SAT | | Last |
| CANCEL | :>/Cancel SAT | EXIT | EXIT |
| INDEX T·C | T·C/Index SAT | BACK | BACK |
| | Power DVD | SHIFT + | Shift + Power |
| DVD | DVD | D | Blue (D) |
| 1 | 1 DVD | SHIFT + 1 | Shift + 1 |
| 2 | 2 DVD | SHIFT + 2 | Shift + 2 |
| 3 | 3 DVD | SHIFT + 3 | Shift + 3 |
| 4 | 4 DVD | SHIFT + 4 | Shift + 4 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 5 | 5 DVD | SHIFT + 5 | Shift + 5 | DVD DISC | Disc DVD | VOD | VOD |
| 6 | 6 DVD | SHIFT + 6 | Shift + 6 | REC AUDIO | Audio DVD | | Audio |
| 7 | 7 DVD | SHIFT + 7 | Shift + 7 | CANCEL | :>/ Cancel DVD | SHIFT + EXIT | Shift + EXIT |
| 8 | 8 DVD | SHIFT + 8 | Shift + 8 | FR.D. | Pause/ FR. D. | SHIFT + II | Shift + Pause |
| 9 | 9 DVD | SHIFT + 9 | Shift + 9 | INDEX T-C | T· C/ Index DVD | SHIFT + BACK | Shift + BACK |
| 0 | 0 DVD | SHIFT + 0 | Shift + 0 | | | | |
| GUIDE MENU | Menu/ Guide | SHIFT + MENU | Shift + MENU | | | | |
| OK | OK DVD | SHIFT + OK | Shift + OK | | | | |
| | Up DVD | SHIFT + ▲ | Shift + UP | | | | |
| | Down DVD | SHIFT + ▼ | Shift + DOWN | | | | |
| | Right DVD | SHIFT + ▶ | Shift + RIGHT | | | | |
| | Left DVD | SHIFT + ◀ | Shift + LEFT | | | | |
| ▶ | Play DVD | II | Pause | | | | |
| ■ | Stop DVD | SHIFT + ■ | Shift + Stop | | | | |
| i NEWS/TA | i / News/ TA DVD | SHIFT + INFO | Shift + INFO | | | | |
| CHANNE |I< | Channel / Track DVD | ◀◀ | Rewind | | | |
| L/TRACK |>I | Channel / Track >I DVD | ▶▶ | Fast Forward | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power VCR | | Power |
| VCR | VCR | C | Yellow (C) |
| MUTE | Mute VCR | | MUTE |
| 1 | 1 VCR | 1 | 1 |
| 2 | 2 VCR | 2 | 2 |
| 3 | 3 VCR | 3 | 3 |
| 4 | 4 VCR | 4 | 4 |
| 5 | 5 VCR | 5 | 5 |
| 6 | 6 VCR | 6 | 6 |
| 7 | 7 VCR | 7 | 7 |
| 8 | 8 VCR | 8 | 8 |
| 9 | 9 VCR | 9 | 9 |
| 0 | 0 VCR | 0 | 0 |
| GUIDE MENU | Menu/Guide | MENU | MENU |
| | Up VCR | ▲ | UP |
| OK | OK VCR | OK | OK |
| | Down VCR | ▼ | DOWN |

| Original | | Replacement | |
|---|---|---|---|
| | Right VCR | ▶ | RIGHT |
| | Left VCR | ◀ | LEFT |
| + | Vol + VCR | + VOL | VOL + |
| − | Vol - VCR | VOL − | VOL - |
| ▶ | Play VCR | ▶ | Play |
| ■ | Stop VCR | ■ | Stop |
| CHANNE | I< Channel/Track VCR | ⏮ | First |
| L/TRACK | Channel/Track >I VCR | ⏭ | Last |
| REC AUDIO | Rec VCR | ● | Rec |
| CANCEL | :>/Cancel VCR | EXIT | EXIT |
| FR.D. | Pause/FR.D VCR | ❚❚ | Pause |
| INDEX T·C | T·C/Index VCR | BACK | BACK |
| | Power | SHIFT + | Shift + Power |
| CDR/TAPE | CDR/Tape | D | Blue (D) |
| 1 | 1 CDR/Tape | SHIFT + 1..? | Shift + 1 |
| 2 | 2 CDR/Tape | SHIFT + 2ABC | Shift + 2 |
| 3 | 3 CDR/Tape | SHIFT + 3DEF | Shift + 3 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| 4 CDR/Tape | SHIFT + 4 | DVD DISC Disc CDR/Tape | VOD VOD |
| 5 CDR/Tape | SHIFT + 5 | | |
| 6 CDR/Tape | SHIFT + 6 | | |
| 7 CDR/Tape | SHIFT + 7 | | |
| 8 CDR/Tape | SHIFT + 8 | | |
| 9 CDR/Tape | SHIFT + 9 | | |
| 0 CDR/Tape | SHIFT + 0 | | |
| Up CDR/Tape | SHIFT + ▲ | | |
| Down CDR/Tape | SHIFT + ▼ | | |
| Right CDR/Tape | SHIFT + ▶ | | |
| Left CDR/Tape | SHIFT + ◀ | | |
| i / News/TA | INFO | | |
| I< Channel / Track CDR/Tape | Rewind | | |
| Channel / Track >I CDR/Tape | Fast Forward | | |
| Rec CDR/Tape | WIDE | | |
| : >/ Cancel | SHIFT + EXIT | | |
| Pause/FR. D. CDR/Tape | SHIFT + II | | |