Mandis shop

Philips 996510052928

Original		Replacement	
	Power		Power
SOURCE A	Source A	A	Red
SOURCE B	Source B	B	Green
LIGHT	Light	HOME SMART	Smart
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK▶II	OK	OK	Ok
OK▶II	Play/Pause	PLAY MODE ▶	Play
FM	FM	C	Yellow
⏮	I<<	⏮	I<<
MENU ■	Stop	■	Stop
MENU ■	Menu	TOP MENU MENU	Menu
⏭	>>I	⏭	>>I
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -

Original		Replacement	
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MODE	Mode	APP MEDIA	Media
PROG	Prog	PROG SLEEP	Sleep
DBB	DBB	AD SUBT	Subt
DSC	DSC	SOUND DUAL	Dual
MAX SOUND	MAX Sound	FAV PRE-CH	Pre Ch