Original		Replacement	
	Power		Power
	TV / Video		TV/R
	DVD		Smart
	VCR		Media
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Display		Info
	Up		Up

Original		Replacement	
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Stop		Stop
	Play		Play
	Pause / Step		Pause
	<< REW		<<
	>> FWD		>>
	Record		Rec
	Clear		Exit

Original		Replacement	
	Power		Power
	Open / Close		Eject
	DVD	HOME SMART	Smart
	VCR	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
RETURN	Return	RETURN BACK	Back
DISPLAY	Display	DISPLAY INFO	Info
LIST/DISC MENU	List / Disc Men	E-MANUAL D.MENU	D. Menu

Original		Replacement	
SYSTEM MENU	System Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	I<		I<<
	>I		>>I
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE/STEP	Pause / Step		Pause
REW	<< REW		<<
FWD	>> FWD		>>
THUMBNAIL	Thumbnail	ECO 3D	3D
CHAPTER	Chapter	PICTURE FORMAT	Format
TIMER	Timer	TIMER AV	AV
RECORD	Record	REC MODE	Rec

Original	Replacement	Original	Replacement
REC MODE Rec. Mode	D Blue		
REPEAT Repeat	REPEAT TEXT Text		
TITLE Title	SETTINGS OPT Options		
AUDIO Audio	SOUND DUAL Dual		
ZOOM Zoom	SHIFT + ZOOM Shift + Eject		
SEARCH Search	SEARCH TV/R TV/R		
MARKER Marker	FAV PRE-CH Pre Ch		
D.DUBBING D. Dubbing	-/-- GUIDE Guide		
CLEAR Clear	CLEAR EXIT Exit		
SHOWVIEW VIDEOPLUS+ Showview / VideoPlus+	AD SUBT Subt		