| Original | | Replacement | |
|---|---|---|---|
| | Standby / On | | Power |
| | Search | SEARCH TV/R | TV/R |
| | Display | DISPLAY INFO | Info |
| | Repeat | REPEAT TEXT | Text |
| | Repeat A-B | SHIFT + | REPEAT TEXT Shift + Text |
| | Audio | SOUND DUAL | Dual |
| | Subtitle | AD SUBT | Subt |
| | Zoom | ZOOM | Eject |
| | Angle | PICTURE FORMAT | Format |
| | Return | RETURN BACK | Back |
| | Title | DISC NAV LIST | List |
| | Clear | CLEAR EXIT | Exit |
| | >>I | >>I | >>I |
| | I << | I << | I << |
| | DVD | HOME SMART | Smart |
| | Disc Menu | E-MANUAL D.MENU | D. Menu |
| | System Menu | TOP MENU MENU | Menu |

| Original | | Replacement | |
|---|---|---|---|
| | Up | | Up |
| | Left | | Left |
| | OK | | Ok |
| | Right | | Right |
| | Down | | Down |
| | Stop | | Stop |
| | Play | | Play |
| | Pause | | Pause |
| | Marker | FAV PRE-CH | Pre Ch |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | |
|---|---|---|---|
| STANDBY ON | Standby / On | | Power |
| SEARCH | Search | SEARCH TV/R | TV/R |
| DISPLAY | Display | DISPLAY INFO | Info |
| CLEAR/RESET | Clear | CLEAR EXIT | Exit |
| VCR | VCR | HOME SMART | Smart |
| VCR/TV | TV / VCR | APP MEDIA | Media |
| SYSTEM MENU | System Menu | TOP MENU MENU | Menu |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | Ok |
| | Right | | Right |
| | Down | | Down |
| | << | | << |
| | >> | | >> |
| STOP | Stop | | Stop |
| PLAY | Play | PLAY MODE | Play |
| PAUSE | Pause | | Pause |

| Original | | Replacement | |
|---|---|---|---|
| MARKER | Marker | FAV PRE-CH | Pre Ch |
| RECORD | Rec | REC MODE | Rec |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |