| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| MODE | Mode | FORMAT PICTURE | Picture / Format |
| SCAN | Scan | LIST SMART | Smart / List |
| DIM | DIM | TOP MENU D.MENU | D. Menu / Top |
| TIMER | Timer | SHIFT + | TIMER SLEEP Shift + Sleep / Timer |
| | Eject | SURROUND | Eject / Surround |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| MENU | Menu | HOME MENU | Menu / Home |
| INFO RDS | RDS/Info | ANGLE INFO | Info / Angle |
| ALBUM | Album Up | | Up |
| | Album Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | OK |
| | I< | PRESET- | I<< / Preset- |
| | Play | SLOW | Play / Slow |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |

| Original | | Replacement | |
|---|---|---|---|
| | Stop | HOLD | Stop / Hold |
| | >I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| LOUDNESS | Loudness | EQ SUBTITLE | Subtitle / EQ |
| CLOCK | Clock | MEDIA DISPLAY | Display / Media |
| + VOL | Vol + | + VOL | Vol + |
| VOL – | Vol - | VOL – | Vol - |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| TREBLE | Treble | + CH PAGE | CH+ / Page+ |
| BASS | Bass | CH PAGE – | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |

| Original | | Replacement | |
|---|---|---|---|
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| PROGRAM | Program | PROGRAM TV/ RADIO | TV/ Radio / |
| SHIFT | Shift | RDS AV INPUT | AV / Input / RDS |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| MODE | Mode | FORMAT PICTURE | Picture / Format |
| SCAN | Scan | LIST SMART | Smart / List |
| DIM | DIM | TOP MENU D.MENU | D. Menu / Top |
| TIMER | Timer | SHIFT + | TIMER SLEEP Shift + Sleep / Timer |
| | Eject | SURROUND | Eject / Surround |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| MENU | Menu | HOME MENU | Menu / Home |
| INFO RDS | RDS/Info | ANGLE INFO | Info / Angle |
| ALBUM | Album Up | | Up |
| | Album Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | OK |
| | I< | PRESET- | I<< / Preset- |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |

| Original | | Replacement | |
|---|---|---|---|
| | Stop | HOLD | Stop / Hold |
| | >I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| LOUDNESS | Loudness | EQ SUBTITLE | Subtitle / EQ |
| CLOCK | Clock | MEDIA DISPLAY | Display / Media |
| + VOL | Vol + | + VOL | Vol + |
| VOL – | Vol - | VOL – | Vol - |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| TREBLE | Treble | + CH PAGE | CH+ / Page+ |
| BASS | Bass | CH PAGE – | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| PROGRAM | Program | PROGRAM TV/ RADIO | TV/ Radio / | | |
| SHIFT | Shift | RDS AV INPUT | AV / Input / RDS | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| MODE | Mode | FORMAT PICTURE | Picture / Format |
| SCAN | Scan | LIST SMART | Smart / List |
| DIM | DIM | TOP MENU D.MENU | D. Menu / Top |
| TIMER | Timer | SHIFT + TIMER SLEEP | Shift + Sleep / Timer |
| | Eject | SURROUND | Eject / Surround |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| MENU | Menu | HOME MENU | Menu / Home |
| INFO RDS | RDS/Info | ANGLE INFO | Info / Angle |
| ALBUM | Album Up | | Up |
| | Album Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | OK |
| | I< | PRESET- | I<< / Preset- |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |

| Original | | Replacement | |
|---|---|---|---|
| | Stop | HOLD | Stop / Hold |
| | >I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| LOUDNESS | Loudness | EQ SUBTITLE | Subtitle / EQ |
| CLOCK | Clock | MEDIA DISPLAY | Display / Media |
| + VOL | Vol + | + VOL | Vol + |
| VOL – | Vol - | VOL – | Vol - |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| TREBLE | Treble | + CH PAGE | CH+ / Page+ |
| BASS | Bass | CH PAGE – | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| PROGRAM | Program | PROGRAM TV/ RADIO | TV/ Radio / | | |
| SHIFT | Shift | RDS AV INPUT | AV / Input / RDS | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| MODE | Mode | FORMAT PICTURE | Picture / Format |
| DIM | DIM | TOP MENU D.MENU | D. Menu / Top |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| SCAN | Scan | LIST SMART | Smart / List |
| TIMER | Timer | SHIFT + | TIMER SLEEP Shift + Sleep / Timer |
| MENU | Menu | HOME MENU | Menu / Home |
| INFO RDS | RDS/Info | ANGLE INFO | Info / Angle |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| LOUDNESS | Loudness | EQ SUBTITLE | Subtitle / EQ |
| CLOCK | Clock | MEDIA DISPLAY | Display / Media |
| + VOL | Vol + | + VOL | Vol + |
| VOL – | Vol - | VOL – | Vol - |
| TREBLE | Treble | + CH PAGE | CH+ / Page+ |
| BASS | Bass | CH PAGE – | CH- / Page- |
| | << | TUNE- | << / Tune- |
| | Play | SLOW | Play / Slow |

| Original | | Replacement | |
|---|---|---|---|
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | I < | PRESET- | I << / Preset- |
| | >> | TUNE+ | >> / Tune+ |
| | Stop | HOLD | Stop / Hold |
| | >I | PRESET+ | >>I / Preset+ |
| OK | OK | OK | OK |
| ALBUM | Album Up | | Up |
| | Album Down | | Down |
| | Right | | Right |
| | Left | | Left |
| PROGRAM | Program | PROGRAM TV/RADIO | TV/Radio / |
| | Eject | SURROUND | Eject / Surround |
| SHIFT | Shift | RDS AV INPUT | AV / Input / RDS |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |

| Original | | Replacement | |
|---|---|---|---|
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| Power | DAB/ FM | SHIFT + Power | Shift + Power |
| SCAN | Scan DAB/ FM | SHIFT + LIST SMART | Shift + Smart / List |
| OK | OK DAB/ FM | SHIFT + OK | Shift + OK |
| ALBUM ▲ | Album Up | SHIFT + ▲ | Shift + Up |
| ▼ | Album Down | SHIFT + ▼ | Shift + Down |
| ▶ | Right DAB/ FM | SHIFT + ▶ | Shift + Right |
| MODE | Mode DAB/ FM | SHIFT + FORMAT PICTURE | Shift + Picture / Format |
| ◀ | Left DAB/ FM | SHIFT + ◀ | Shift + Left |
| MENU | Menu DAB/ FM | SHIFT + HOME MENU | Shift + Menu / |
| INFO RDS | RDS/ Info | SHIFT + ANGLE INFO | Shift + Info / Angle |
| 1 | 1 DAB/ FM | SHIFT + TV 1 | Shift + 1 |

| Original | | Replacement | |
|---|---|---|---|
| 2 | 2 DAB/ FM | SHIFT + DVD 2 | Shift + 2 |
| 3 | 3 DAB/ FM | SHIFT + CD - STB 3 | Shift + 3 |
| 4 | 4 DAB/ FM | SHIFT + VIDEO 4 | Shift + 4 |
| 5 | 5 DAB/ FM | SHIFT + TAPE 5 | Shift + 5 |
| 6 | 6 DAB/ FM | SHIFT + TUNER 6 | Shift + 6 |
| 7 | 7 DAB/ FM | SHIFT + AUX - HDD 7 | Shift + 7 |
| 8 | 8 DAB/ FM | SHIFT + USB 8 | Shift + 8 |
| 9 | 9 DAB/ FM | SHIFT + BLUETOOTH 9 | Shift + 9 |
| 0 | 0 DAB/ FM | SHIFT + HDMI - SAT 0 | Shift + 0 |
| ⏮ | I < DAB/ FM | SHIFT + PRESET- ⏮ | Shift + I << / Preset - |
| ⏭ | >I DAB/ FM | SHIFT + PRESET+ ⏭ | Shift + >>I / Preset + |
| ◀◀ | << DAB/ FM | SHIFT + TUNE- ◀◀ | Shift + << / |
| ▶▶ | >> DAB/ FM | SHIFT + TUNE+ ▶▶ | Shift + >> / |
| PROGRAM | Program | SHIFT + PROGRAM TV/ RADIO | Shift + TV/ Radio / Program |
| SHIFT | Shift DAB/ FM | SHIFT + RDS AV INPUT | Shift + AV / Input / RDS |