Original	Replacement	Original	Replacement
On/Off	Power	OK Enter	OK
Mute	Mute / Dimmer	Menu Right	Right
Update	Play / Slow	Menu Off	Exit / Cancel / Clear
Reveal	Pause / Step / Freeze	Menu Down	Down
Txt Stop	Stop / Hold	Back	Back / Return
Info	Info / Angle	Volume+	Vol +
Subt. List	Subtitle / EQ	Chan. Up	CH+ / Page+
Return TV	TV/Radio /	Volume-	Vol -
Menu video	D. Menu / Top	Chan. Down	CH- / Page-
Sleep Timer	Sleep / Timer	Menu audio	Audio / Lang I/II
Txt Expand	Zoom / Size	1	1
Text	Text / Goto	2	2
TV/AV	AV / Input / RDS	3	3
Menu	Menu / Home	4	4
Display	Display / Media	5	5
Menu Up	Up	6	6
Menu Left	Left	7	7

Original	Replacement	Original	Replacement
8	USB 8 8		
9	BLUETOOTH 9 9		
Guide -/-- 1.	-/-- GUIDE EPG Guide / EPG / -/--		
0/10	HDMI - SAT 0 0		
2. Fav P/C 2.	PC FAV MARKER Fav / Marker / PC		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Tone+	TUNE+ >> / Tune+		
Store Text	SHIFT + GOTO TEXT Shift + Text /		
Blue	Prime Video RANDOM Blue / Prime Video / Random		
Audio+	PRESET+ >>I / Preset+		
AV 2	SHIFT + RDS AV INPUT Shift + AV / Input / RDS		
Surround	SURROUND Eject / Surround		
Nicam/Mono	TITLE SOUND Sound / Title		

Original	Replacement	Original	Replacement
On/Off	Power	Menu Right	Right
Mute	Mute / Dimmer	Menu Off	Exit / Cancel / Clear
Update	Play / Slow	Menu Down	Down
Reveal	Pause / Step / Freeze	Back	Back / Return
Txt Stop	Stop / Hold	Volume+	Vol +
Info	Info / Angle	Chan. Up	CH+ / Page+
Subt. List	Subtitle / EQ	Menu audio	Audio / Lang I/II
Sleep Timer	Sleep / Timer	Volume-	Vol -
Text	Text / Goto	Chan. Down	CH- / Page-
Txt Expand	Zoom / Size	1	1
Return TV	TV/Radio /	2	2
TV/AV	AV / Input / RDS	3	3
Menu	Menu / Home	4	4
Menu Up	Up	5	5
Display	Display / Media	6	6
Menu Left	Left	7	7
OK Enter	OK	8	8

Original	Replacement	Original	Replacement
9	9	Color + P.Std	Picture / Format
Guide -/-- 1.	Guide / EPG / -/--	AV 2	Shift + AV / Input / RDS
0/10	0	Bright + Mode	Shift + Menu /
2. Fav P/C 2.	Fav / Marker / PC	Search	Shift + Up
Red	Red / Netflix / Search	Disp	Shift + Display / Media
Green	Green / APP / Repeat	Tune-	Shift + Left
Yellow	Yellow / YouTube / Repeat	Aft/Caf	Shift + OK
Blue	Blue / Prime Video / Random	Tune+	Shift + Right
Game Coo	D.Menu / Top	Bright- Sys	Shift + Exit / Cancel / Clear
Audio-	<< / Tune-	Store	Shift + Down
Off/Tim	Setup / OPT /	Browse	Shift + Back / Return
Rotate Text	Shift + Eject / Surround	Input	Shift + Vol +
Tone-	I<< / Preset-	Color- S.Std	Sound / Title
Audio+	>> / Tune+	Contrast+	Shift + CH+ /
Mix Scan	Smart / List	Output	Shift + Vol -
Store Text	Shift + Text /	Contrast-	Shift + CH- /
Tone+	>>I / Preset+	On Pip	Shift + 1

Original	Replacement	Original	Replacement
Swap	SHIFT + DVD 2	Shift + 2	
Rotate Pip	SHIFT + CD - STB 3	Shift + 3	
Still	SHIFT + VIDEO 4	Shift + 4	
Dim Pip	SHIFT + TAPE 5	Shift + 5	
Help	SHIFT + TUNER 6	Shift + 6	
Camera	SHIFT + AUX - HDD 7	Shift + 7	
Nicam/Mono	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II	
Surround	SURROUND ⏏	Eject / Surround	
Camera1	SHIFT + USB 8	Shift + 8	
Clear	SHIFT + BLUETOOTH 9	Shift + 9	
3.*	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--	
View	SHIFT + HDMI - SAT 0	Shift + 0	
4.# 16:9	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC	
Level L	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /	
Level R/Woofer	SHIFT + Prime Video RANDOM	Shift + Blue / Prime	