Mandis shop

Samsung AH59-02692C

Original		Replacement		Original	Replacement
	Power		Power		
SOURCE	Source	TIMER AV	AV		
VOL +	Vol +	+ VOL	Vol +		
VOL -	Vol -	VOL −	Vol -		
	Mute	MUTE	Mute		
	Back	RETURN BACK	Back		
	I<<		I<<		
	Play	PLAY MODE ▶	Play		
	Pause		Pause		
	>>I		>>I		
SOUND EFFECT	Sound Effect	SETTINGS OPT	Options		
SOUND	Sound	SOUND DUAL	Dual		
SOUND CONTROL	Sound Control	AD SUBT	Subt		
STREAMING MUSIC	Streaming	APP MEDIA	Media		
WOOFER	Woofer	SEARCH TV/R	TV/R		
Anynet+	Anynet*	HOME SMART	Smart		