Original		Replacement	
	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
SLEEP	Sleep	PROG SLEEP	Sleep
REMAIN	Remain	DISC NAV LIST	List
DVD	DVD	D	Blue
TUNER BAND	Band/Tuner	C	Yellow
TAPE	Tape	B	Green
AUX	AUX	A	Red
SLOW MO/ST	Mo/ST/Slow	SOUND DUAL	Dual
SUB TITLE	Subtitle	AD SUBT	Subt
COUNTER RESET STEP	Step/Counter	SHIFT +	Shift + Pause
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
REPEAT	Repeat	REPEAT TEXT	Text
	I<<		I<<
	Stop		Stop
	Play/<>	PLAY MODE	Play
	Pause		Pause

Original		Replacement	
	>>I		>>I
SRS WOW	SRS Wow	PICTURE FORMAT	Format
VOLUME +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
TUNING	Tuning Up	+ CH	Ch +
	Tuning Down	CH –	Ch -
EQ/S.BASS	EQ / S. Bass	APP MEDIA	Media
RETURN	Return	RETURN BACK	Back
MENU	Menu	TOP MENU MENU	Menu
INFO	Info	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
RDS DISPLAY 1	1/RDS Display	1	1

Original		Replacement	
2	2	2	2
TA 3	3/ TA	3	3
PTY- 4	4/ PTY-	4	4
PTY SEARCH 5	5/ PTY Search	5	5
PTY+ 6	6/ PTY+	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
REP.A↔B	Repeat A↔B	SHIFT + REPEAT TEXT	Shift + Text
CANCEL	Cancel	CLEAR EXIT	Exit
TREBLE/BASS	Treble/Bass	SHIFT + SOUND DUAL	Shift + Dual
EZ VIEW	EZ View /	-/-- GUIDE	Guide
SLIDE MODE	Slide Mode	SHIFT + PICTURE FORMAT	Shift + Format
DIGEST	Digest	ECO 3D	3D
TIMER ON/OFF	Timer On/Off	TIMER AV	AV
LOGO	Logo	SETTINGS OPT	Options

Original		Replacement	
TUNER MEMORY	Tuner Memory	REC MODE	Rec
TIMER/CLOCK	Timer Clock	SHIFT + TIMER AV	Shift + AV