Mandis shop

Sony RM-S171

Original		Replacement	
I/⏻	Power	⏻	Power
DISPLAY	Display	DISPLAY INFO	Info
DSG	DSG	ZOOM ⏏	Eject
CD ▶	Play CD	PLAY MODE ▶	Play
⏸	Pause CD	⏸	Pause
■	Stop CD	■	Stop
TUNER/BAND	Play	SHIFT + PLAY MODE ▶	Shift + Play
⏮	I<</- Tuner	⏮	I<<
⏭	>>I/+ Tuner	⏭	>>I
TAPE ◀▶	Play/<> Tape	SETTINGS OPT	Options
◀◀	<< Tape	◀◀	<<
▶▶	>> Tape	▶▶	>>
DIR MODE	Play Dir Mode	HOME SMART	Smart
FM MODE	FM Mode	SOUND DUAL	Dual
REC	Rec	REC MODE ●	Rec
CD REPEAT	CD Repeat	REPEAT TEXT	Text
FUNCTION	Function	TOP MENU MENU	Menu

Original		Replacement	
TUNING MODE/PLAY MODE	Tuning Mode/Play Mode	PICTURE FORMAT	Format
MEMORY	Up/Memory	▲	Up
SLEEP	Down/Sleep	▼	Down
TIMER SELECT	Right/Timer	▶	Right
TIMER SET	Left/Timer Set	◀	Left
ENTER ON/OFF	Enter/On/Off	OK	Ok
VOL +	Vol+	+ VOL	Vol +
VOL −	Vol-	VOL −	Vol -

https://remotecontrols.dk/en/Sony/1058653-5964-replacement-remote-control-for-Sony-RM-S171-147723911.html