Original		Replacement	
TV I/⏻	Standby TV	⏻	Power
TV/VIDEO SLEEP	Tv/Video TV	SEARCH TV/R	TV/R
TV CH + PRESET +	CH+ TV	+ CH	Ch +
TV CH − PRESET −	CH- TV	CH −	Ch -
TV VOL MASTER VOL +	Vol + TV	+ VOL	Vol +
−	Vol - TV	VOL −	Vol -
1	1 TV	1	1
2	2 TV	2	2
3	3 TV	3	3
4	4 TV	4	4
5	5 TV	5	5
6	6 TV	6	6
7	7 TV	7	7
8	8 TV	8	8
9	9 TV	9	9
0/10	0/10 TV	0	0
>10 -/-- CLEAR	-/-- TV	-/-- GUIDE	Guide

Original		Replacement	
MEMORY D.SKIP	Enter/Memory/D.Skip TV	FAV PRE-CH	Pre Ch
AV I/⏻	Standby AV Video	SHIFT + ⏻	Shift + Power
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	APP MEDIA	Media
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
TEST TONE	Test Tone	HOME SMART	Smart
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A.F.D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
MAIN MENU	Main Menu	TOP MENU MENU	Menu
FM MODE MPX AUDIO	MPX/FM Mode/Audio Video	SHIFT + SEARCH TV/R	Shift + TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Video 1	AD SUBT	Subt

Original	Replacement
Enter/Memory/D.Skip Video 1	SHIFT + FAV PRE-CH Shift + Pre Ch
1 Video 1	SHIFT + 1 Shift + 1
2 Video 1	SHIFT + 2 Shift + 2
3 Video 1	SHIFT + 3 Shift + 3
4 Video 1	SHIFT + 4 Shift + 4
5 Video 1	SHIFT + 5 Shift + 5
6 Video 1	SHIFT + 6 Shift + 6
7 Video 1	SHIFT + 7 Shift + 7
8 Video 1	SHIFT + 8 Shift + 8
9 Video 1	SHIFT + 9 Shift + 9
0/10 Video 1	SHIFT + 0 Shift + 0
-/--/>10/Clear Video 1	SHIFT + GUIDE Shift + Guide
AV Menu Video	TIMER AV AV
Up Video 1	Up
Down Video 1	Down
Right Video 1	Right
Left Video 1	Left

Original	Replacement
Enter Video 1	OK Ok
Display Video	DISPLAY INFO Info
Master Vol +	SHIFT + VOL + Shift + Vol +
Master Vol -	SHIFT + VOL − Shift + Vol -
Muting	MUTE Mute
Play Video 1	PLAY MODE ▶ Play
Pause Video 1	⏸ Pause
Stop Video 1	■ Stop
TUNING − <<Tuning- Video	<<
TUNING + >>Tuning+	>>
TV CH − PRESET − I<<Preset+	I<<
TV CH + PRESET + >>I/Preset + Video 1	>>I
STEP ADVANCE →Advance/Step I> Video 1	SHIFT + CH + Shift + Ch +
STEP REPLAY ←/Replay/<I Step Video 1	SHIFT + CH − Shift + Ch -

Original	Replacement
Standby System	Power
Standby AV	Shift + Power
Sleep	Sleep
Test Tone	Smart
Play	Play
>>/ Tuning+	>>
<</ Tuning-	<<
Pause	Pause
Stop	Stop
Main Menu	Menu
Video 1	Red
Video 2	Green
SA-CD/CD	Yellow
DVD	Blue
Tuner	Media
1	1
2	2

Original	Replacement
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/10	0
-/--/>10/Clear	Guide
Enter/Memory/D.S	Pre Ch
Top	Shift + Menu
AV Menu	AV
Muting	Mute
Return/Exit	Back
Display	Info
Master Vol +	Vol +
Master Vol -	Vol -

Original		Replacement	
PRESET –	I <</ Preset -		I <<
PRESET +	>>I / Preset +		>>I
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
ADVANCE	·→Advance/ Step I >	CH +	Ch +
REPLAY	← / Replay/ <I Step	CH –	Ch -
MUSIC	Music	SOUND DUAL	Dual
MOVIE	Movie	PICTURE FORMAT	Format
A.F.D.	A. F. D.	SETTINGS OPT	Options
DUAL MONO	Dual Mono	ECO 3D	3D
2CH	2CH	REPEAT TEXT	Text
FM MODE AUDIO	MPX/ FM	SEARCH TV/R	TV/ R
D.TUNING SUBTITLE	ANT/ D. Tuning/ Subtitle	AD SUBT	Subt
SHIFT ANGLE	Jump/ Shift/ Angle	DISC NAV LIST	List

Original	Replacement

Original		Replacement	
	Standby System		Power
	Standby AV	SHIFT +	Shift + Power
	Sleep	PROG SLEEP	Sleep
	Test Tone	HOME SMART	Smart
	Video 1	A	Red
	Video 2	B	Green
	SA-CD/CD	C	Yellow
	DVD	D	Blue
	Tuner	APP MEDIA	Media
	Main Menu	TOP MENU MENU	Menu
	Music	SOUND DUAL	Dual
	Movie	PICTURE FORMAT	Format
	2CH	REPEAT TEXT	Text
	Dual Mono	ECO 3D	3D
	A. F. D.	SETTINGS OPT	Options
	Enter/Memory/D. S	FAV PRE-CH	Pre Ch
	1	1	1

Original		Replacement	
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0/10	0	0
	-/--/>10/Clear	-/-- GUIDE	Guide
	Master Vol +	+ VOL	Vol +
	Master Vol -	VOL –	Vol -
	Muting	MUTE	Mute
	Display	DISPLAY INFO	Info
	Enter	OK	Ok
	Play	PLAY MODE ▶	Play
	Pause	II	Pause

Original		Replacement		Original	Replacement
	Stop		Stop		
TUNING –	<<Tuning-		<<		
TUNING +	>>Tuning+		>>		
TV CH – PRESET –	I<<Preset-		I<<		
TV CH + PRESET +	>>I / Preset+		>>I		

Original		Replacement	
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	HOME SMART	Smart
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
TV I/⏻	Standby System	⏻	Power
MAIN MENU	Main Menu	TOP MENU MENU	Menu
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A. F. D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
FM MODE MPX AUDIO	MPX/FM Mode/Audio Tuner	SEARCH TV/R	TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Tuner	AD SUBT	Subt
SHIFT ANGLE	Jump/Shift/Angle Tuner	DISC NAV LIST	List
1	1 Tuner	1	1

Original		Replacement	
2	2 Tuner	2	2
3	3 Tuner	3	3
4	4 Tuner	4	4
5	5 Tuner	5	5
6	6 Tuner	6	6
7	7 Tuner	7	7
8	8 Tuner	8	8
9	9 Tuner	9	9
0/10	0/10 Tuner	0	0
MEMORY D.SKIP	Enter/Memory/D.Skip Tuner	FAV PRE-CH	Pre Ch
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Master Vol +	+ VOL	Vol +
−	Master Vol -	VOL −	Vol -
DISPLAY	Display Tuner	DISPLAY INFO	Info
TV CH − PRESET −	I<<Preset- Tune	⏮	I<<
TV CH + PRESET +	>>I/Preset+	⏭	>>I
TUNING −	<<Tuning- Tuner	«	<<

Original	Replacement
TUNING + >>/ Tuning+	>>
TEST TONE Test Tone	APP MEDIA Media
AV Standby Video	SHIFT + Power — Shift + Power
FM MODE MPX AUDIO MPX/ FM Mode/ Audio Video	SHIFT + SEARCH TV/R — Shift + TV/R
D.TUNING SUBTITLE ANT/ D. Tuning/ Subtitle Video 2	SHIFT + AD SUBT — Shift + Subt
MEMORY D.SKIP Enter/ Memory/ D. Skip Video 2	SHIFT + FAV PRE-CH — Shift + Pre Ch
1 Video 2	SHIFT + 1 — Shift + 1
2 Video 2	SHIFT + 2 — Shift + 2
3 Video 2	SHIFT + 3 — Shift + 3
4 Video 2	SHIFT + 4 — Shift + 4
5 Video 2	SHIFT + 5 — Shift + 5
6 Video 2	SHIFT + 6 — Shift + 6
7 Video 2	SHIFT + 7 — Shift + 7
8 Video 2	SHIFT + 8 — Shift + 8
9 Video 2	SHIFT + 9 — Shift + 9
0/ 10 Video 2	SHIFT + 0 — Shift + 0
>10 CLEAR -/ - - / >10/ Clear Video 2	-/-- GUIDE Guide

Original	Replacement
AV MENU/GUIDE AV Menu Video	TIMER AV AV
Up Video 2	Up
Down Video 2	Down
Right Video 2	Right
Left Video 2	Left
ENTER Enter Video 2	OK Ok
DISPLAY Display Video	SHIFT + DISPLAY INFO — Shift + Info
Play Video 2	PLAY MODE Play
Pause Video 2	Pause
Stop Video 2	Stop
REPLAY ← / Replay/ ◁ I Step Video 2	CH − Ch -
ADVANCE · →Advance/ Step I > Video 2	+ CH Ch +
TV CH + PRESET + >>I / Preset+	SHIFT + >>I — Shift + >>I
TV CH − PRESET − I <</ Preset- Vide	SHIFT + I<< — Shift + I<<
TUNING + >>/ Tuning+	SHIFT + >> — Shift + >>
TUNING − <</ Tuning- Video	SHIFT + << — Shift + <<