Original		Replacement	
I/⏻	Power	⏻	Power
EJECT	Eject	ZOOM ⏏	Eject
AUDIO MONITOR	Audio/Monitor	SOUND DUAL	Dual
WIDE	Wide	ECO 3D	3D
COUNTER/ REMAIN	Counter/Remain	HOME SMART	Smart
SLOW	Slow	D	Blue
×2	X2	C	Yellow
INDEX	I<<<Index	I<<	I<<
SEARCH	>>I/Search	>>I	>>I
DISPLAY	[i+]	DISPLAY INFO	Info
SP/LP	SP/LP	PICTURE FORMAT	Format
CLEAR	Clear	CLEAR EXIT	Exit
TV/VIDEO	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4

Original		Replacement	
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+/-	-/--	-/-- GUIDE	Guide
INPUT SELECT	Input Select	FAV PRE-CH	Pre Ch
PROG	Prog+	+ CH	Ch +
	Prog-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
REC	Rec	REC MODE	Rec
TIMER	Timer	SHIFT + TIMER AV	Shift + AV
MENU	Menu	TOP MENU MENU	Menu
SMART SEARCH	Smart Search	APP MEDIA	Media
PAUSE	Up	▲	Up

Original	Replacement	Original	Replacement
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Pause	Pause		
Stop	Stop		
>>	>>		
<<	<<		
Play	Play		

Original	Replacement	Original	Replacement
Power	Power	Vol -	Vol -
Audio Monitor	Dual	Prog+	Ch +
Wide	3D	Prog-	Ch -
Display	Info		
TV/Video	TV/R		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
-/--	Guide		
Vol +	Vol +		