# Mandis shop

RM-S51

| Original | Replacement |
|---|---|
| Power System | Power |
| Function | Menu |
| Sleep | Sleep |
| Tuner / Band | Smart |
| Preset - | Ch - |
| Preset + | Ch + |
| Play Tape Deck A | Up |
| >> Tape Deck | Right |
| << Tape Deck | Left |
| Stop Tape Deck A | Ok |
| Play Tape Deck B | Shift + Up |
| >> Tape Deck | Shift + Right |
| << Tape Deck | Shift + Left |
| Stop Tape Deck B | Shift + Ok |
| Pause Tape Deck | Shift + Down |
| Rec Tape Deck | Shift + Rec |
| Play CD | Play |

| Original | Replacement |
|---|---|
| Pause CD | Pause |
| Stop CD | Stop |
| I << CD | I << |
| >>I CD | >>I |
| Vol + | Vol + |
| Vol - | Vol - |

https://remotecontrols.de/Sony/10224832-replacement-remote-control-for-Sony-RM-S51.htm