Mandis shop

Sony RM-DX250

Original		Replacement	
POWER	Power		Power
CONTINUE	Continue	NETFLIX SEARCH	Red / Netflix / Search
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio /
DISC CAPS	Disc		Left
TRACK SPACE	Track		Up
GROUP DEL	Group		Right
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0

Original		Replacement	
ENTER	Enter	OK	OK
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIME/ TEXT	Time	TIMER SLEEP	Sleep / Timer
MEMO SCAN	Memo Scan	LIST SMART	Smart / List
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
AMS	I<< AMS	PRESET-	I<< / Preset-
AMS	AMS >>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
DISC	Disc Skip -	CH PAGE	CH- / Page-
SKIP	Disc Skip +	CH PAGE	CH+ / Page+

https://remotes.com/Sony-10836950-replacement-remote-control-for-Sony-RM-DX250.htm