Original	Replacement	Original	Replacement
Digital	Display / Media	PTY	Text / Goto
Yellow/Theater Modes	Yellow / YouTube / Repeat	Down	Down
Power	Power	Menu/RDS	Menu / Home
CD	Shift + 3	Vol +	Vol +
DVD	Shift + 2	PR+	CH+ / Page+
Green/Stereo	Green / APP / Repeat	Vol -	Vol -
Blue/Delay	Blue / Prime Video / Random	PR-	CH- / Page-
Red/Center	Red / Netflix / Search	Mute	Mute / Dimmer
Up	Up	1	1
Violet/Level	Fav / Marker / PC	2	2
Tape	Shift + 5	3	3
SAT/CAB	Shift + 0	4	4
Tuner	Shift + 6	5	5
Video/VCR	Shift + 4	6	6
Left/-	Left	7	7
OK	OK	8	8
Right/+	Right	9	9

Original		Replacement	
memo	Memo	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0

Original	Replacement

Original		Replacement		Original		Replacement	
digital	Digital	MEDIA DISPLAY	Display / Media	down	Down		Down
theater modes	Yellow/Theater Modes	YouTube REPEAT A-B	Yellow / YouTube / Repeat	RDS mix	Menu/RDS	HOME MENU	Menu / Home
	Power		Power		Vol +	VOL +	Vol +
cd	CD	SHIFT + CD - STB 3	Shift + 3	pr+	PR+/ >>I	PRESET+	>>I / Preset+
dvd	DVD	SHIFT + DVD 2	Shift + 2	pr+	PR+/ >>I	CH PAGE +	CH+ / Page+
stereo	Green/Stereo	APP REPEAT	Green / APP / Repeat		Vol -	VOL –	Vol -
delay	Blue/Delay	Prime Video RANDOM	Blue / Prime Video / Random	pr–	PR-/I <<	PRESET-	I << / Preset-
dts	Red/Center	NETFLIX SEARCH	Red / Netflix / Search	pr–	PR-/I <<	CH PAGE –	CH- / Page-
up	Up		Up		Mute	DIMMER MUTE	Mute / Dimmer
level	Violet/Level	PC FAV MARKER	Fav / Marker / PC	1	1	TV 1	1
tape	Tape	SHIFT + TAPE 5	Shift + 5	2	2	DVD 2	2
sat/cab	SAT/CAB	SHIFT + HDMI - SAT 0	Shift + 0	3	3	CD - STB 3	3
tuner	Tuner	SHIFT + TUNER 6	Shift + 6	4	4	VIDEO 4	4
video /vcr	Video/VCR	SHIFT + VIDEO 4	Shift + 4	5	5	TAPE 5	5
–	Left/-		Left	6	6	TUNER 6	6
ok	OK	OK	OK	7	7	AUX - HDD 7	7
+	Right/+		Right	8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
memo	Memo	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
REV	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FWD	>>	TUNE+	>> / Tune+
DISC REC vcr	Rec	REC MODE	Rec / Rec Mode
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze

Original	Replacement

Original	Replacement	Original	Replacement
Digital	Display / Media	PTY	Text / Goto
Yellow/Theater Mo	Yellow / YouTube / Repeat	Down	Down
Power	Power	Menu/RDS	Menu / Home
CD	SHIFT + CD-STB 3 Shift + 3	Vol +	Vol +
DVD	SHIFT + DVD 2 Shift + 2	PR+/ >>I	CH+ / Page+
Green/Stereo	Green / APP / Repeat	Vol -	Vol -
Blue/Delay	Blue / Prime Video / Random	PR- / I <<	CH- / Page-
Red/Center	Red / Netflix / Search	Mute	Mute / Dimmer
Up	Up	1	1
Violet/Level	Fav / Marker / PC	2	2
Tape	SHIFT + TAPE 5 Shift + 5	3	3
SAT/CAB	SHIFT + HDMI-SAT 0 Shift + 0	4	4
Tuner	SHIFT + TUNER 6 Shift + 6	5	5
Video/VCR	SHIFT + VIDEO 4 Shift + 4	6	6
Left/-	Left	7	7
OK	OK	8	8
Right/+	Right	9	9

Original	Replacement	Original	Replacement
Memo	Smart / List		
0	0		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Digital	Display / Media	Right / +	Right
Yellow/ Theater Modes	Yellow / YouTube / Repeat	PTY	Text / Goto
Power	Power	Down	Down
CD	Shift + 3	Menu/ RDS	Menu / Home
DVD	Shift + 2	Menu/ RDS	AV / Input / RDS
Green/ Stereo	Green / APP / Repeat	Vol +	Vol +
Blue/ Delay	Blue / Prime Video / Random	PR+/ >>I	CH+ / Page+
Red/ Center	Audio / Lang I/II	PR+/ >>I	>>I / Preset +
Red/ Center	Red / Netflix / Search	Vol -	Vol -
Up	Up	PR- / I <<	CH- / Page-
Violet / Level	Fav / Marker / PC	PR- / I <<	I << / Preset -
Tape	Shift + 5	Mute	Mute / Dimmer
SAT/ CAB	Shift + 0	1	1
Tuner	Shift + 6	2	2
Video/ VCR	Shift + 4	3	3
Left / -	Left	4	4
OK	OK	5	5

Original		Replacement		Original	Replacement
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
memo	Memo	LIST SMART	Smart / List		
0	0	HDMI - SAT 0	0		
REV	<<	TUNE-	<< / Tune-		
PLAY	Play	SLOW	Play / Slow		
FWD	>>	TUNE+	>> / Tune+		
DISC REC vcr	Rec	REC MODE	Rec / Rec Mode		
STOP	Stop	HOLD	Stop / Hold		
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze		