Mandis shop

I CUBE500

Original		Replacement	
	Power		Power
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
ROTATE	Rotate	FORMAT PICTURE	Picture / Format
DEVICE	Device	RDS AV INPUT	AV / Input / RDS
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SLOW	Slow	SHIFT + SLOW	Shift + Play /
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
INTERVAL	Interval	TOP MENU D.MENU	D. Menu / Top
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TV SYSTEM	Tv System	LIST SMART	Smart / List
VOL+	Vol +	+ VOL	Vol +
	Up		Up
NEXT	Next	PRESET+	>>I / Preset +
	Left		Left

Original		Replacement	
ENTER	Enter	OK	OK
	Right		Right
VOL-	Vol -	VOL –	Vol -
	Down		Down
PREV.	Prev	PRESET-	I<< / Preset -
MENU	Menu	HOME MENU	Menu / Home
PLAY	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
FR	<<I FR	TUNE-	<< / Tune-
FF	>>I FF	TUNE+	>> / Tune+
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
RETURN	X/ Return	RETURN BACK	Back / Return
RETURN	X/ Return	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MOVIE	Movie	NETFLIX SEARCH	Red / Netflix / Search
MUSIC	Music	APP REPEAT	Green / APP / Repeat
PHOTO	Photo	YouTube REPEAT A-B	Yellow / YouTube / Repeat
FILE	File	Prime Video RANDOM	Blue / Prime Video / Random

https://remotes.de/Woxter/1394-226-replacement-remote-control-for-Woxter-i-Cube-500.htm