




































Originalfernbedienung Ersatzfernbedienung

|                                                                                     |            |                                                                                     |        |
|-------------------------------------------------------------------------------------|------------|-------------------------------------------------------------------------------------|--------|
|    | On/Standby |    | Power  |
|    | 1          |    | 1      |
|    | 2          |    | 2      |
|    | 3          |    | 3      |
|    | 4          |    | 4      |
|    | 5          |    | 5      |
|    | 6          |    | 6      |
|    | 7          |    | 7      |
|    | 8          |    | 8      |
|   | 9          |   | 9      |
|  | 10         |  | 0      |
|  | +10        |  | Guide  |
|  | +100       |  | Pre Ch |
|  | Display    |  | Info   |
|  | Cancel     |  | Back   |
|  | Set        |  | Menu   |
|                                                                                     | Sleep      |  | Sleep  |

Originalfernbedienung Ersatzfernbedienung

|                                                                                       |               |                                                                                                                                                                           |              |
|---------------------------------------------------------------------------------------|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|
|    | Group Up      |                                                                                        | Up           |
|    | Group Down    |                                                                                        | Down         |
|    | >>I           |                                                                                        | >>I          |
|    | >>I           |                                                                                        | Right        |
|    | I<<           |                                                                                        | I<<          |
|    | I<<           |                                                                                        | Left         |
|    | Stop          |                                                                                        | Stop         |
|    | Stop          |                                                                                        | Ok           |
|    | Play Mode     |  +  | Shift + Play |
|   | AUX           |                                                                                       | Red          |
|  | Play/Pause CD |                                                                                      | Play         |
|  | <> Tape       |                                                                                      | Yellow       |
|  | Tuner Band    |                                                                                      | Blue         |
|  | Repeat        |                                                                                      | Text         |
|  | Reverse Mode  |                                                                                      | TV/R         |
|  | FM Mode       |                                                                                      | Media        |
|  | Sound         |                                                                                      | Dual         |



