





































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------------|---|------------|
|  | Power |  | Power |
|  | Sleep / Timer |  | Sleep |
|  | Sleep / Timer |  | Shift + AV |
|  | Display |  | Info |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | P↔P |  | Back |
|  | P↔P |  | Pre Ch |









Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------------|---|---------|
|  | Menu |  | Menu |
|  | Up / P+ |  | Up |
|  | Up / P+ |  | Ch + |
|  | Down / P- |  | Down |
|  | Down / P- |  | Ch - |
|  | Right / Vol+ |  | Right |
|  | Right / Vol+ |  | Vol + |
|  | Left / Vol- |  | Left |
|  | Left / Vol- |  | Vol - |
|  | Enter |  | Ok |
|  | Input Select |  | AV |
|  | Text / Mix |  | Text |
|  | Normal |  | Smart |
|  | Skip |  | Media |
|  | Audio 1/2 |  | Dual |
|  | Status |  | D. Menu |
|  | Red |  | Red |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------------|---|--------|
|  | Green |  | Green |
|  | Yellow |  | Yellow |
|  | Blue |  | Blue |
|  | Picture Size |  | Eject |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Originalfernbedienung Ersatzfernbedienung

| | |
|--|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

