




























































	Original	Replacement		Original	Replacement
	Power		Power		Exit
	Mute		Mute		Up
	1		1		Down
	2		2		Right
	3		3		Left
	4		4		Ok
	5		5		Vol +
	6		6		Vol -
	7		7		Sound
	8		8		Pic
	9		9		Ch +
	0		0		Ch -
	Audio		Dual		Sleep
	Recall		Back		Aspect
	Tv Menu		Menu		Freeze
	Source		AV		Tv/Radio
	ChList		List		Text
					Exit
					Up
					Down
					Right
					Left
					Ok
					Vol +
					Vol -
					Shift + Dual
					Shift + Format
					Ch +
					Ch -
					Sleep
					Format
					Eject
					TV/R
					Text



