





























































Original	Replacement
 Power	 Power
 Input	 AV
 Digital/Analog	 3D
 TV/Radio	 TV/R
 Exit	 Exit
 EXT.Box Menu	 D. Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [i+]/[?]	 Info

Original	Replacement
 [≡]	 Text
 Google Play	 Shift + Smart
 Netflix	 Media
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Guide	 Guide
 Action Menu	 Menu
 APPS	 Shift + Media
 Back	 Back
 TV	 Options
 Home	 Smart
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





	Original	Replacement		Original	Replacement
	OK	 Ok		Help	 Format
	Vol+	 Vol +		Title List	 List
	Vol-	 Vol -			
	Mute	 Mute			
	Recall	 Pre Ch			
	Prog+	 Ch +			
	Prog-	 Ch -			
	Audio	 Dual			
	<<	 <<			
	Play	 Play			
	>>	 >>			
	I<<	 I<<			
	Pause	 Pause			
	>>I	 >>I			
	Rec	 Rec			
	Stop	 Stop			
	[...]	 Subt			

