



Original	Replacement
Power	Power
Repeat	Text
A-B	+ Shift + Text
Open / Close	Eject
N / P	TV/R
Subtitle	Subt
Angle	Format
Language	Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement
0	0
10+	Guide
Time	AV
Setup	Options
Title	Media
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
PBC	Smart
Menu	Menu
Vol -	Vol -
Vol +	Vol +
Zoom	+ Shift + Eject
Return	Back
L / R	+ Shift + Dual





Original	Replacement	Original	Replacement
Step	+ Shift + Pause		
Slow	+ Shift + Play		
Clear	EXIT Exit		
Program	PROG SLEEP Sleep		
Mute	MUTE Mute		
Display	DISPLAY INFO Info		
Prev <<	<< <<		
Next >>	>> >>		
Rev <<	<< <<		
Fwd >>	>> >>		
Stop	Stop Stop		
Play / Pause	PLAY MODE Play		
Play / Pause	Pause Pause		
V-Mode	ECO 3D 3D		

Original	Replacement

