














































































Original	Replacement
	Power
	Sleep
	Mute
	Mode
	1
	2
	3
	Eject / Surround
	Sound / Title
	4
	5
	6
	Text / Goto
	Play / Slow
	Pause / Step / Freeze
	7
	8

Original	Replacement
	9
	Exit / Cancel / Clear
	Stop / Hold
	Guide / EPG / -/--
	0
	Back / Return
	Menu / Home
	Rec / Rec Mode
	Up
	CH+ / Page+
	TV/Radio /
	Left
	OK
	Right
	Vol-
	Down
	CH- / Page-





Original	Replacement
 Vol+	 Vol+
 Return	 +  Shift + Back / Return
 Menu DVD	 D.Menu / Top
 Setup	 Setup / OPT /
 Display	 Display / Media
 Search/FAV	 +  Shift + Red / Netflix /
 Search/FAV	 Fav / Marker / PC
 Slow/EPG	 +  Shift + Play /
 Slow/EPG	 +  Shift + Guide / EPG / -/--
 Language/Info	 Audio / Lang I/II
 Language/Info	 Info / Angle
 Zoom/List	 Zoom / Size
 Zoom/List	 Smart / List
 Red/Angle	 Red / Netflix / Search
 Red/Angle	 +  Shift + Info / Angle
 Green/Program	 Green / APP / Repeat
 Green/Program	 +  Shift + TV/Radio / Program

Original	Replacement
 Yellow/Repeat	 +  Shift + Green / APP /
 Yellow/Repeat	 Yellow / YouTube / Repeat
 Blue/A-B	 Blue / Prime Video / Random
 Blue/A-B	 +  Shift + Yellow / YouTube /
 <</Hold	 +  Shift + Stop /
 <</Hold	 << / Tune-
 >>/Index	 >> / Tune+
 I<</Size	 I<< / Preset-
 I<</Size	 +  Shift + Zoom /
 >>I/Reveal	 >>I / Preset+
 Subtitle	 Subtitle / EQ
 Title/Subpage	 +  Shift + Sound / Title
 FAV-	 +  Shift + Down
 FAV+	 +  Shift + Up

