



	Original	Replacement		Original	Replacement
	Power		Power		Ch.List
	Source		AV		P +
	1		1		P -
	2		2		Media.P
	3		3		Menu
	4		4		Guide
	5		5		Tools
	6		6		Info
	7		7		Up
	8		8		Right
	9		9		Down
	0		0		Left
	TTX/MIX		Text		Enter
	PRE-CH		Pre Ch		Return
	Vol+		Vol +		Exit
	Vol-		Vol -		Red
	Mute		Mute		Green





Original	Replacement	Original	Replacement
 Yellow	 Yellow		
 Blue	 Blue		
 P.Mode	 +  Shift + Format		
 Dual I/II	 Dual		
 3D	 3D		
 AD	 +  Shift + Subt		
 P.Size	 Format		
 Subt.	 Subt		
 <<	 <<		
 Pause	 Pause		
 >>	 >>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

