



































































































Original		Replacement		Original		Replacement	
	Power		Power		Pop Up Menu		D. Menu
	Open/Close		Eject		Return		Back
	Setting		Options		Top Menu		Menu
	1		1		Up		Up
	2		2		Left		Left
	3		3		OK		Ok
	4		4		Right		Right
	5		5		Down		Down
	6		6		Repeat		Text
	7		7		A-B		TV/R
	8		8		Goto		List
	9		9		Display		Info
	0		0		<</<<		<<
	OSC		Guide		Play/Pause		Play
	Clear		Exit		>>/ >>		>>
	Home2		Media		<<		<<
	Home		Smart		Stop		Stop





Original		Replacement		Original	Replacement
	I>/II>		Pause		
	>>I		>>I		
	Red/Program		Red		
	Red/Program		Sleep		
	Green/Digest		Green		
	Yellow/Zoom		Yellow		
	Yellow/Zoom		Shift + Eject		
	Blue/Bookmark		Blue		
	Subtitle		Subt		
	Audio		Dual		
	PIP		Format		
	PIP Audio		3D		
	Angle		Pre Ch		
	HDMI		AV		

