



Originalfernbedienung	Ersatzfernbedienung
	Power
	Up
	Enter
	Down
	Right
	Left
	Menu
	Esc
	Reset
	Position
	Freeze
	Magnify On
	Magnify Off
	Search
	Video
	RGB
	Aspect

Originalfernbedienung	Ersatzfernbedienung
	Blank
	Auto
	Mute
	Volume
	Keystone
	Page Up
	Page Down
	Home
	End
	Hide / Blank
	Auto / Mode
	Mute / Focus
	Vol +
	Vol -
	3
	6 / Comp
	2
	5 / VGA2

