






































































Originalfernbedienung Ersatzfernbedienung

	Mute		Mute / Dimmer
	TFT On/Off		Power
	Setup		Setup / OPT /
	Angle		Info / Angle
	DVD/USB/Card		Shift + 2
	OSD		Display / Media
	Search		Red / Netflix / Search
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Menu		Menu / Home
	Up		Up
	Title		Sound / Title
	Left		Left
	OK		OK
	Right		Right
	Zoom		Zoom / Size
	Down		Down

Originalfernbedienung Ersatzfernbedienung

	Vol+		Vol+
	1		1
	2		2
	3		3
	Vol-		Vol-
	4		4
	5		5
	6		6
	Repeat		Green / APP / Repeat
	7		7
	8		8
	9		9
	Program		TV/Radio /
	0/10		0
	10+		Guide / EPG / -/-
	Stop		Stop / Hold
	Play		Play / Slow





Originalfernbedienung Ersatzfernbedienung

PLAY/PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PREV	I<</Prev	PRESET-	I<< / Preset-
NEXT	>>I/Next	PRESET+	>>I / Preset+
REV	<</REV	TUNE-	<< / Tune-
FWD	>>/FWD	TUNE+	>> / Tune+

Originalfernbedienung Ersatzfernbedienung

