









































































































































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
 Power Receiver	 Power	 4	 4
 Power CD/LD	 Shift + Power	 5	 5
 Power Tape/Tv	 TV/R	 6	 6
 Master	 Vol +	 7	 7
 Master Volume	 Vol -	 8	 8
 Return	 Back	 9	 9
 Direct/Test	 Info	 0/10	 0
 Func/Tape 2	 Menu	 Stop CD/LD	 Stop
 Delay/Center -	 Dual	 Play CD/LD	 Play
 Center M/Center	 Options	 <</I<< CD/LD	 <<
 Surr/Rear -	 Subt	 >>/I>> CD/LD	 >>
 Muting/Rear +	 Mute	 Disc-/Side A	 Left
 Direct	 Smart	 Disc+/Side B	 Right
 Class/Display	 Media	 Stop Tape/Tv	 Shift + Stop
 1	 1	 << Tape/Tv	 I<<
 2	 2	 >> Tape/Tv	 >>I
 3	 3	 < Tape/Tv	 Down





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
 Power Receiver	 Power	 4	 4
 Power CD/LD	 Shift + Power	 5	 5
 Power Tape/Tv	 TV/R	 6	 6
 Master	 Vol +	 7	 7
 Master Volume-	 Vol -	 8	 8
 Return	 Back	 9	 9
 Direct/Test	 Info	 0/10	 0
 Func/Tape 2	 Menu	 Stop CD/LD	 Stop
 Delay/Center -	 Dual	 Play CD/LD	 Play
 Center M/Center	 Options	 <</I<< CD/LD	 <<
 Surr/Rear -	 Subt	 >>/I>> CD/LD	 >>
 Muting/Rear +	 Mute	 Disc-/ Side A	 Left
 Direct	 Smart	 Disc+/ Side B	 Right
 Class/Display	 Media	 TV Vol-/Deck I Tape/Tv	 Ch -
 1	 1	 Tv Vol+/Deck II Tape/Tv	 Ch +
 2	 2	 < Tv Func	 I<<
 3	 3		

