
































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	DTV		Shift + 1
	Radio		TV/Radio /
	USB		Shift + 8
	DVD		Shift + 2
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	TV Guide		Guide / EPG / -/--
	0		0

Originalfernbedienung Ersatzfernbedienung

	Recall		Back / Return
	Vol +		Vol+
	P.Mode		Picture / Format
	CH +		CH+ / Page+
	Vol -		Vol-
	S.Mode		Sound / Title
	CH -		CH- / Page-
	FAV		Fav / Marker / PC
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Source		AV / Input / RDS
	Down		Down
	Info		Info / Angle





















**Originalfernbedienung Ersatzfernbedienung**

	Aspect		Shift + Picture / Format
	Sleep		Sleep / Timer
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Text Hold		Shift + Stop /
	Text/DVD Zoom		Zoom / Size
	Display Power		Display / Media
	Display Power		Shift + Power
	Rec / DVD Menu		D.Menu / Top
	Rec / DVD Menu		Rec / Rec Mode
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Stop / Open/Close		Eject / Surround
	Stop / Open/Close		Stop / Hold
	Rec List / DVD Setup		Smart / List
	Rec List / DVD Setup		Setup / OPT /

**Originalfernbedienung Ersatzfernbedienung**

	<<		<< / Tune-
	>>		>> / Tune+
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	Red / Goto		Red / Netflix / Search
	Green / A-B		Green / APP / Repeat
	Yellow / Angle /		Yellow / YouTube / Repeat
	Blue / Repeat		Blue / Prime Video / Random

