







































































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------------|---|--------------|
|  | TV / DVD / USB |  | Media |
|  | Radio |  | TV/R |
|  | Display |  | Info |
|  | Mute |  | Mute |
|  | Angle |  | Format |
|  | Menu / PBC |  | Menu |
|  | L / R |  | Shift + Dual |
|  | Language |  | Dual |
|  | Subtitle |  | Subt |
|  | Title |  | Smart |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------------|---|---------------|
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | 10+ |  | Shift + Guide |
|  | Up / CH + |  | Up |
|  | Up / CH + |  | Ch + |
|  | Down / CH - |  | Down |
|  | Down / CH - |  | Ch - |
|  | Right |  | Right |
|  | Left |  | Left |
|  | Play / Enter |  | Ok |
|  | Play / Enter |  | Play |
|  | Slow |  | Shift + Play |
|  | Pause |  | Shift + Pause |
|  | Stop |  | Stop |
|  | Setup |  | Options |
|  | << |  | << |



