



**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	Source Search		TV/R
	Video		Green
	USB		Yellow
	Lan		Blue
	Computer		Red
	1		1
	1		Guide
	2		2
	3		3
	4		4
	5		5
	6		6
	Auto		List
	7		7
	Aspect		Format
	8		8

**Originalfernbedienung    Ersatzfernbedienung**

	Color Mode		Options
	9		9
	0		0
	Menu		Menu
	ESC		Exit
	User		Back
	Pointer		Info
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right
	Down		Down
	Page Up		Ch +
	Page Down		Ch -
	E-Zoom+		Shift + Ch +
	E-Zoom-		Shift + Ch -
	Vol+		Vol +



