





































































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------|---|---------|
|  | Power |  | Power |
|  | Eject |  | Eject |
|  | Disc |  | 1 |
|  | HDMI1/Roku |  | 2 |
|  | HDMI2 |  | 3 |
|  | HDMI3/Aple |  | 4 |
|  | Bluetooth |  | 5 |
|  | AUX |  | 6 |
|  | TV |  | 7 |
|  | Radio |  | TV/R |
|  | Pop Up |  | D. Menu |
|  | Display |  | Info |
|  | Top Menu |  | Menu |
|  | Surround |  | Dual |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------|---|---------|
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | I<< |  | I<< |
|  | >>I |  | >>I |
|  | << |  | << |
|  | >> |  | >> |
|  | Play |  | Play |
|  | Stop |  | Stop |
|  | Pause |  | Pause |
|  | Recall |  | Pre Ch |
|  | (10) |  | Media |
|  | [::] |  | Guide |
|  | Home |  | Smart |
|  | *≡ |  | Options |
|  | Back |  | Back |
|  | Up |  | Up |
|  | Down |  | Down |



