



**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	Mute		Mute
	Red/F1		Red
	Green/F2		Green
	Yellow/F3		Yellow
	Blue/IPTV		Blue
	<<		<<
	Play		Play
	Pause		Pause
	Stop		Stop
	>>		>>
	V.Format		Format
	Resolution		3D
	Subtitle		Subt
	Rec		Rec
	Option		Options
	Audio		Dual

**Originalfernbedienung    Ersatzfernbedienung**

	Text		Text
	SAT		Smart
	Info		Info
	Recall		Back
	Menu		Menu
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	FAV		Pre Ch
	EPG		Guide
	Page+		Ch +
	Page-		Ch -



