





































































Originalfernbedienung Ersatzfernbedienung

|   |        |   |       |
|---|--------|---|-------|
|    | Power  |    | Power |
|    | Sleep  |    | Sleep |
|    | Mute   |    | Mute  |
|    | 1      |    | 1     |
|    | 2      |    | 2     |
|    | 3      |    | 3     |
|    | 4      |    | 4     |
|    | 5      |    | 5     |
|    | 6      |    | 6     |
|    | 7      |    | 7     |
|   | 8      |   | 8     |
|  | 9      |  | 9     |
|  | 0      |  | 0     |
|  | -/--   |  | Guide |
|  | Recall |  | Back  |
|  | Audio  |  | Dual  |
|  | P.M.   |  | Smart |

Originalfernbedienung Ersatzfernbedienung

|   |                      |   |              |
|---|----------------------|---|--------------|
|    | Info                 |    | Info         |
|    | Input                |    | AV           |
|    | Up / CH+             |    | Up           |
|    | Up / CH+             |    | Ch +         |
|    | Down / CH-           |    | Down         |
|    | Down / CH-           |    | Ch -         |
|    | Right / Vol+ / Enter |    | Right        |
|    | Left / Vol-          |    | Left         |
|    | Left / Vol-          |    | Vol -        |
|    | Right / Vol+ / Enter |    | Vol +        |
|   | Right / Vol+ / Enter |   | Ok           |
|  | Menu                 |  | Menu         |
|  | Page+                |  | >>           |
|  | Page-                |  | <<           |
|  | Display              |  | Shift + Info |
|  | Exit                 |  | Exit         |
|  | Red                  |  | Red          |





| Originalfernbedienung   |            | Ersatzfernbedienung   |         | Originalfernbedienung |  | Ersatzfernbedienung |  |
|---|------------|---|---------|-----------------------|--|---------------------|--|
|    | Green      |    | Green   |                       |  |                     |  |
|    | Yellow     |    | Yellow  |                       |  |                     |  |
|    | Blue       |    | Blue    |                       |  |                     |  |
|    | Size       |    | Eject   |                       |  |                     |  |
|    | Stop       |    | Stop    |                       |  |                     |  |
|    | Reveal     |    | TV/R    |                       |  |                     |  |
|    | Index      |    | Options |                       |  |                     |  |
|    | 4:3 / 16:9 |    | Format  |                       |  |                     |  |
|    | C.Lock     |    | Media   |                       |  |                     |  |
|   | Sub.PG     |   | Subt    |                       |  |                     |  |
|  | On/Mix/Off |  | Text    |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |
|   |            |   |         |                       |  |                     |  |

