































Originalfernbedienung Ersatzfernbedienung

|   |         |   |               |
|---|---------|---|---------------|
|    | Power   |    | Power         |
|    | Mute    |    | Mute          |
|    | 1       |    | 1             |
|    | 2       |    | 2             |
|    | 3       |    | 3             |
|    | 4       |    | 4             |
|    | 5       |    | 5             |
|    | 6       |    | 6             |
|    | 7       |    | 7             |
|    | 8       |    | 8             |
|   | 9       |   | 9             |
|  | 0       |  | 0             |
|  | -/--    |  | Shift + Guide |
|  | Recall  |  | Back          |
|  | Display |  | Info          |
|  | Source  |  | AV            |
|  | Up      |  | Up            |

Originalfernbedienung Ersatzfernbedienung

|   |             |   |                |
|---|-------------|---|----------------|
|    | Left        |    | Left           |
|    | Enter       |    | Ok             |
|    | Right       |    | Right          |
|    | Down        |    | Down           |
|    | Exit        |    | Exit           |
|    | Menu        |    | Menu           |
|    | Vol+        |    | Vol +          |
|    | Vol-        |    | Vol -          |
|    | S.Mode      |    | Shift + Dual   |
|    | CH+         |    | Ch +           |
|   | CH-         |   | Ch -           |
|  | Audio I/II  |  | Dual           |
|  | P.Mode      |  | Shift + Format |
|  | Auto        |  | Smart          |
|  | Sleep       |  | Sleep          |
|  | Aspect      |  | Format         |
|  | Red / Eject |  | Red            |



























**Originalfernbedienung    Ersatzfernbedienung**

|   |                   |   |              |
|---|-------------------|---|--------------|
|    | Red / Eject       |    | Eject        |
|    | Green / D.Menu    |    | Green        |
|    | Green / D.Menu    |    | D. Menu      |
|    | Yellow / Setup    |    | Yellow       |
|    | Yellow / Setup    |    | Options      |
|    | Blue / D.Disp     |    | Blue         |
|    | Blue / D.Disp     |    | List         |
|    | Play/Pause / Text |    | Text         |
|    | Play/Pause / Text |    | Play         |
|   | Play/Pause / Text |   | Pause        |
|  | Stop / Index      |  | Stop         |
|  | A-B / MIX         |  | Shift + TV/R |
|  | Repeat / Reveal   |  | Shift + Text |
|  | << / Hold         |  | Shift + Stop |
|  | << / Hold         |  | <<           |
|  | >> / Subpage      |  | >>           |
|  | >> / Subpage      |  | Shift + Subt |

**Originalfernbedienung    Ersatzfernbedienung**

|   |              |   |               |
|---|--------------|---|---------------|
|    | I<< / Size   |    | I<<           |
|    | I<< / Size   |    | Shift + Eject |
|    | >>I / Cancel |    | >>I           |
|    | >>I / Cancel |    | Shift + Exit  |
|    | Time Shift   |    | Media         |
|    | Rec          |    | Rec           |
|    | FAV-         |    | Shift + Left  |
|    | FAV+         |    | Shift + Right |
|    | EPG          |    | Guide         |
|   | FAV          |   | Pre Ch        |
|  | Subtitle     |  | Subt          |
|  | TV / Radio   |  | TV/R          |
|   |              |   |               |
|   |              |   |               |
|   |              |   |               |
|   |              |   |               |
|   |              |   |               |
|   |              |   |               |

