












































Originalfernbedienung Ersatzfernbedienung

|   |               |   |                             |
|---|---------------|---|-----------------------------|
|    | Red/Sound     |    | Sound / Title               |
|    | Red/Sound     |    | Red / Netflix / Search      |
|    | Green/Picture |    | Picture / Format            |
|    | Green/Picture |    | Green / APP / Repeat        |
|    | Yellow/P.     |    | Yellow / YouTube / Repeat   |
|    | Blue/VT       |    | Blue / Prime Video / Random |
|    | Ino           |    | Smart / List                |
|    | TV            |    | TV/Radio /                  |
|    | Zoom-/Stop    |    | Down                        |
|    | Zoom+/Func VI |    | Up                          |
|   | -             |   | Vol-                        |
|  | +             |  | Vol+                        |
|  | Prog.-        |  | CH- / Page-                 |
|  | Prog.+        |  | CH+ / Page+                 |
|  | 1             |  | 1                           |
|  | 2             |  | 2                           |
|  | 3             |  | 3                           |

Originalfernbedienung Ersatzfernbedienung

|   |       |   |                  |
|---|-------|---|------------------|
|  | 4     |  | 4                |
|  | 5     |  | 5                |
|  | 6     |  | 6                |
|  | 7     |  | 7                |
|  | 8     |  | 8                |
|  | 9     |  | 9                |
|  | Mute  |  | Mute / Dimmer    |
|  | 0/AV  |  | 0                |
|  | 0/AV  |  | AV / Input / RDS |
|  | Power |  | Power            |

