



































**Originalfernbedienung    Ersatzfernbedienung**

|   |                |   |         |
|---|----------------|---|---------|
|    | Mute           |    | Mute    |
|    | Power          |    | Power   |
|    | Tuner/Band     |    | Green   |
|    | AUX            |    | Red     |
|    | Timer/Clock    |    | Pre Ch  |
|    | Timer On/Off   |    | Exit    |
|    | Program/Set    |    | Menu    |
|    | Mo/ST/Rep A-B  |    | Dual    |
|    | Sleep          |    | Sleep   |
|    | EQ/S.Bass      |    | Options |
|  | Tape Speed     |  | Format  |
|  | Power Sound    |  | Media   |
|  | Display        |  | Info    |
|  | RDS-PTY        |  | TV/R    |
|  | Play CD/MP3-CD |  | Play    |
|  | Pause          |  | Pause   |
|  | Stop           |  | Stop    |

**Originalfernbedienung    Ersatzfernbedienung**

|   |               |   |              |
|---|---------------|---|--------------|
|    | I<< CD/MP3-CD |    | I<<          |
|    | >>I CD/MP3-CD |    | >>I          |
|    | Repeat        |    | Text         |
|    | Volume+       |    | Vol +        |
|    | Volume-       |    | Vol -        |
|    | Tuning/Album  |    | Ch +         |
|    | Tuning/Album  |    | Ch -         |
|    | +10Tuning     |    | Guide        |
|    | << Tape       |    | <<           |
|    | >> Tape       |    | >>           |
|  | Play Tape     |  | Shift + Play |
|  | Stop Tape     |  | Shift + Stop |
|   |               |   |              |
|   |               |   |              |
|   |               |   |              |
|   |               |   |              |
|   |               |   |              |
|   |               |   |              |
|   |               |   |              |
|   |               |   |              |



CD/MP3-CD