

















































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Eject		Eject
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/10		0
	10+		Guide































Originalfernbedienung Ersatzfernbedienung

	Tv/Radio		TV/R
	Menu		Menu
	Return		Back
	Language		Dual
	Subtitle		Subt
	Title/TTX		Text
	Prog/EPG		Sleep
	Display		Info
	L/R		Media
	Enter		Ok
	Up		Up
	Down		Down
	Left/FAV-		Left
	Right/FAV+		Right
	Play		Play
	Stop		Stop
	<<		<<





Originalfernbedienung Ersatzfernbedienung

	>>		>>
	<<		<<
	>>		>>
	Setup		Options
	Repeat		Shift + Text
	3D		3D
	Pause/Step		Pause
	Preview		Blue
	Zoom		Shift + Eject
	A-B		Smart
	Angle		Red
	Slow		Green
	Goto		Yellow
	Video		Pre Ch
	P/N		Exit

Originalfernbedienung Ersatzfernbedienung