














































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	Source		AV / Input / RDS
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	I/II/Audio		Audio / Lang I/II
	P.Size		Zoom / Size
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Originalfernbedienung Ersatzfernbedienung

	-/--		Shift + Guide / EPG / -/--
	Jump		Smart / List
	Menu		Menu / Home
	Info		Info / Angle
	Sleep		Sleep / Timer
	Exit		Exit / Cancel / Clear
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Vol+		Vol+
	Vol-		Vol-
	P-		CH- / Page-
	P+		CH+ / Page+
	Red/D.Setup		Red / Netflix / Search
	Red/D.Setup		Setup / OPT /





Originalfernbedienung Ersatzfernbedienung

	Green/Repeat		Green / APP / Repeat
	Yellow/Zoom		Yellow / YouTube / Repeat
	Yellow/Zoom		Shift + Zoom / Zoom /
	Blue/Goto		Blue / Prime Video / Random
	Blue/Goto		Shift + Text / Text /
	[≡i]/FAV.CH		Fav / Marker / PC
	[≡?]/Freeze		Shift + Pause / Step / Step /
	[≡♦]/USB/SD		Shift + 8
	[≡+]/Tv/Radio		TV/Radio /
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Open/Close		Eject / Surround
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-

Originalfernbedienung Ersatzfernbedienung

	>>I		>>I / Preset+
	DVD Menu		D.Menu / Top
	Text		Text / Goto
	Subtitle		Subtitle / EQ
	Guide		Guide / EPG / -/--

