

DGM
TV
AR148

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
	STANDBY		P/Ch +	CH+	SKIP NEXT
MUTE	MUTE	EJECT	P/Ch -	CH-	SKIP PREV.
1	1		VOL +	VOL+	
2	2		VOL -	VOL-	
3	3			UP	
4	4			DOWN	
5	5		OK	ENTER	FAV
6	6			LEFT	FAV-
7	7			RIGHT	FAV+
8	8		MENU	MENU	
9	9		EXIT RETURN	EXIT / DVD SETUP	
0/10	0		TOP MENU	AUTO	S. MODE
GUIDE	C / L	---	PICT TITLE	ASPECT	P. MODE
FAV	FAV	---	EPG	EPG	REVEAL / ANGLE
AUTO/TRK	SLEEP	AUDIO		??	
SUBT	SUBTITLE	SUBTITLE		HOLD / MEDIA	STOP
AV Dvd/Tv	INPUT	??		SIZE / EJECT	SUBPAGE / ZOOM
	DISPLAY	PVR		PVR LIST	INDEX
TEXT	TEXT	TS	RED	RED / PROG.	REC
TV	TV/RADIO / AUDIO		GREEN	GREEN / INTRO	REW
BACK	BACK		YELLOW	YELLOW / REPEAT	PLAY / PAUSE
			BLUE	BLUE / A-B	FWD