

GOSAT
 SAT/DTT
 GS 7056 HDI

Mandis Shop S.L.
 Sant Cugat del Vallès - Barcelona
 info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	POWER	SLEEP	V	DOWN	PAGE DOWN
MUTE	MUTE		EXIT	EXIT	
1	1		BACK	BACK	
2	2		VOL+	VOL+	STEP
3	3		VOL-	VOL-	
4	4		INFO	INFO	
5	5		FAV(LIST)	FAV	
6	6		CH+	CH+	P+
7	7		CH-	CH-	P-
8	8		TEXT	TEXT	>[=]
9	9		< ?	[[[]	OPEN BOOK
0	0		...	???	
VOD	> <		TV/RADIO	TV / AV	
MENU	MENU		OPT+	???	BOOK
>PLAY	PLAY	YELLOW	SOURCE	SAT	
PAUSE	PAUSE		V-FORMAT	V. FORMAT	
[]STOP	STOP		WIDE	ZOOM	
oRECORD	REC	RED			
<<	REW	GREEN			
>>	FWD	BLUE			
<<					
>>	STEP	STEP			
RED	RED	RED			
GREEN	GREEN	GREEN			
YELLOW	YELLOW	YELLOW			
BLUE	BLUE	BLUE			
MEDIA					
EPG(GUIDE)	GUIDE	PHOTO			
OK	OK	SELECT			
^	UP	PAGE UP			
<	LEFT				
>	RIGHT				