

PANASONIC
DVD
N2QAJB000070

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power	Sleep	V	Down	
MUTE			EXIT	Cancel	
1	1/Disc 1		BACK	Return	
2	2/Disc 2		VOL+	Sequential	
3	3/Disc 3		VOL-	FL Select	
4	4/Disc 4		INFO	Display	
5	5/Disc 5		PAUSE (1S)	Open/Close	
6	6		CH+		
7	7		CH-		
8	8		TEXT	Play Mode	
9	9		< 2	Audio	
0	0		...	Subtitle	
VOID	Top Menu/Direct NAvigator		TV/RADIO	Quick Replay	
MENU	Menu/Play List		OP+	Group	
>PLAY	Play		SOURCE	Angle/Page	
PAUSE	Pause		V-FORMAT	Zoom	
STOP	Stop		WIDE	Double/Re-Master	
oRECORD	Position Memory				
<<	<<				
>>	>>				
<<	<<				
>>	>>				
RFD	Disc				
GREEN					
YELLOW					
BLUE					
MEDIA	Setup				
EPG/GUIDE	+10				
OK	Enter				
^	Up				
<	Left				
>	Right				