

VESTEL
TV
RC2240

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power		V	Down	
MUTE	Mute		EXIT	[≡?]/Exit	
1	1		BACK		
2	2		VOL+	Vol+	
3	3		VOL-	Vol-	
4	4		INFO	[≡i]/Info	
5	5		PAV(LIST)	P<P	
6	6		CH+	P+	
7	7		CH-	P-	
8	8		TEXT	Text	
9	9		<?	[≡+]/I-ll	
0	0		...	[.=]/Subt	
VOID	Tv/DTV		TV/RADIO	[≡o]	
MENU	Menu		CFI+	[≡◆]/Guide	
>PLAY			SOURCE	AV	
PAUSE			V-FORMAT		
[STOP]			WIDE	[≡x]/Wide	
◊RECORD					
<<					
>>					
<<					
>>					
RFD	Red/↑				
GRFN	Green/↓				
YELLOW	Yellow				
BLUE	Blue				
MEDIA					
EPG/GUIDE	--				
OK	Select				
∧	Up				
<	Left				
>	Right				