
































































Original	Replacement
 Power	 Power
 Source	 SRC
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX/MIX	 TEXT
 PRE-CH	 P/C / FAV
 Vol+	 VOL +
 Vol-	 VOL -
 Mute	 MUTE

Original	Replacement
 P+	 CH +
 P-	 CH -
 CH List	 TV/R
 Content	 Shift + VOD
 Menu	 MENU
 Guide	 -/-- / EPG
 Tools	 OPT+
 Info	 INFO
 Return	 BACK
 Exit	 EXIT
 Up	 UP
 Down	 DOWN
 Right	 RIGHT
 Left	 LEFT
 Enter	 OK
 Red	 Red (A)
 Green	 Green (B)





Original		Replacement		Original		Replacement	
	Yellow		Yellow (C)				
	Blue		Blue (D)				
	Media. P		MEDIA				
	Internet/@TV		VOD				
	Dual I-II		Audio				
	AD		WIDE				
	P.Size		V-FOR				
	Subt.		Subt.				
	<<		Rewind				
	Pause		Pause				
	>>		Fast Forward				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

