





































































Original	Replacement
 Power	 Power
 My Apps	 Media
 TV/Radio	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 Q.View	 Format
 Input	 AV
 Q.Menu/Subtitle	 Subt

Original	Replacement
 Guide	 Guide
 Info	 Info
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Page+	 Ch +
 Page-	 Ch -
 Text	 Text
 T.Opt	 Options
 Smart	 Smart
 FAV	 Pre Ch
 Back	 Back
 Exit	 Exit
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right





Original	Replacement	Original	Replacement
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Stop/Line TV		Stop
	Rec/*		Rec
	Play		Play
	Pause		Pause
	>>		>>
	<<		<<
	APP/*	 + 	Shift + Media
	AD	 + 	Shift + Subt
	Settings	 + 	Shift + Options

