




























































































	Original	Replacement		Original	Replacement
	Power		Power		Vol +
	Mute		Mute		Vol -
	1		1		Ok
	2		2		Up
	3		3		Down
	4		4		Right
	5		5		Left
	6		6		Menu
	7		7		Exit
	8		8		Sleep
	9		9		Format
	0		0		Rec
	Recall		Pre Ch		Red
	PR.List		List		Green
	Source		AV		Yellow
	CH+		Ch +		Blue
	CH-		Ch -		Options





Original	Replacement	Original	Replacement
 Zoom/Tv/Radio	 TV/R	 Rec List	 Shift + Subt
 I/II Audio	 Dual		
 Subtitle	 Subt		
 Info/Display	 Info		
 Step/Freeze	 Back		
 Prog/Index	 Media		
 A-B/Reveal	 D. Menu		
 Text/Eject	 Text		
 Play/Size	 Play		
 Pause/Subpage	 Pause		
 Stop/Hold	 Stop		
 I<<	 I<<		
 >>I	 >>I		
 <<	 <<		
 >>	 >>		
 S.Mode	 Shift + Dual		
 Pic.Mode	 Shift + Format		

Original	Replacement	Original	Replacement
 Rec List	 Shift + Subt		

