








































































Original	Replacement	Original	Replacement
 Power	 Power	 Skipe	 Media
 Select Drive	 List	 I<<	 I<<
 1	 1	 >>I	 >>I
 2	 2	 << Slow Search	 <<
 3	 3	 Slow Search >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause/Pause Live	 Pause
 6	 6	 Play/x.1.3	 Play
 7	 7	 Rec	 Rec
 8	 8	 i/Status	 Info
 9	 9	 X/Exit	 Exit
 0	 0	 Option	 Options
 Last View	 Pre Ch	 Return	 Back
 Radio/Tv	 TV/R	 Guide	 Guide
 CH/Page Up	 Ch +	 Direct Navigator/PopUp	 D. Menu
 CH/Page Down	 Ch -	 Function Menu	 Menu
 Internet	 Smart	 Up	 Up





Original	Replacement	Original	Replacement
 Down	 Down	 Manual Skip -10s	 Shift + Format
 Right/ >	 Right	 Manual Skip +60s	 Shift + 3D
 Left/<	 Left	 Power Tv	 Shift + Power
 OK	 Ok	 AV Input Tv	 Shift + AV
 Red	 Red	 Vol+ Tv	 Vol +
 Green	 Green	 Vol- Tv	 Vol -
 Yellow	 Yellow	 CH+ Tv	 Shift + Ch +
 Blue	 Blue	 CH- Tv	 Shift + Ch -
 Rec Mode	 Shift + Rec		
 ≡/Text	 Text		
 [≡♦]/STTL	 Subt		
 Prog/Check	 Format		
 Chapter	 3D		
 Time Slip	 Sleep		
 Audio	 Dual		
 Input Select	 AV		
 DEL	 Mute		

