









































































































Original	Replacement
 Power	 Power
 Tv/Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 AV/Input Select	 AV
 -/--	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Tracking/V-Lock+	 Ch +

Original	Replacement
 Tracking/V-Lock-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Prog/Check+	 Shift + 1
 Prog/Check-	 Shift + 4
 Date+	 Shift + 2
 Date-	 Shift + 5
 On+	 Shift + 3
 On-	 Shift + 6
 Off+	 Shift + 9
 Off-	 Shift + Pre Ch





Original	Replacement	Original	Replacement
	Power		Power
	Tv/Text		Text
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	AV/Input Select		AV
	Tracking/V-Lock+		Ch +
	Tracking/V-Lock-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Replay		Options
	OSD/Display		Info
	Search		TV/R
	Showview		Media
	Direct Tv Rec		Smart
	I<< Index		I<<
	Index >>I		>>I
	Rec		Rec
	Pause/Step		Pause
	Play		Play
	Stop		Stop
	>>		>>
	<<		<<
	OK		Ok
	Up		Up
	Down		Down



