



Original		Replacement		Original		Replacement	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Ok		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Sound		Shift + Dual
	8		8		Pic		Shift + Format
	9		9		Ch+		Ch +
	0		0		Ch-		Ch -
	Audio		Dual		Sleep		Sleep
	Recall		Back		Aspect		Format
	Tv Menu		Menu		Freeze		Eject
	Source		AV		Tv/Radio		TV/R
	ChList		List		Text		Text





	Original	Replacement		Original	Replacement
	Epg	Guide		I<<	I<<
	Fav	Pre Ch		>>I	>>I
	Info	Info		Play	Play
	Red	Red		Pause	Pause
	Green	Green		Stop	Stop
	Yellow	Yellow		Rec/Rep	Rec
	Blue	Blue			
	Reveal	Media			
	Hold	D. Menu			
	Index	Shift + Info			
	Subpage	Shift + AV			
	List	Smart			
	Mix	Options			
	Subtitle	Subt			
	Size	3D			
	<<	<<			
	>>	>>			

