





















































Original	Replacement
 Power	 Power
 DVB Menu	 D.Menu / Top
 Open/Close	 Eject / Surround
 Prog+	 CH+ / Page+
 Prog-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 TV/TXT/Tv Format	 Shift + Text /
 Cancel/Text	 Shift + Exit / Cancel / Clear
 Reveal/Info	 Shift + Info / Angle
 Stop	 Stop / Hold
 Hold/Language	 Shift + Stop /
 Size/FAV	 Shift + Zoom /
 Subpage/EPG	 Shift + Guide / EPG / -/-
 Index	 Setup / OPT /
 <<	 << / Tune-

Original	Replacement
 Red	 Red / Netflix / Search
 Tv/Radio	 TV/Radio /
 >>	 >> / Tune+
 Green/Audio	 Green / APP / Repeat
 I<<	 I<< / Preset-
 Yellow/Freeze	 Yellow / YouTube / Repeat
 >>I	 >>I / Preset+
 Blue/Subtitle	 Blue / Prime Video / Random
 CH+	 Shift + CH+ /
 Tv-Menu	 Shift + Menu /
 Vol+	 Vol+
 CH-	 Shift + CH- /
 Tv/AV	 AV / Input / RDS
 Vol-	 Vol-
 +5V	 Shift + 5
 Sleep	 Sleep / Timer
 Up	 Up





Original	Replacement
	 Left
	 OK
	 Right
	 Down
	 Mute / Dimmer
	 Display / Media
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Guide / EPG / -/--
	0

Original	Replacement
	 Back / Return
	 Picture / Format
	 Sound / Title
	 Shift + Picture / Format
	 Audio / Lang I/II
	 Zoom / Size
	 Shift + 2
	 Menu / Home
	 Subtitle / EQ
	 Shift + TV/Radio / Program
	 Info / Angle
	 Shift + Sound / Title
	 Text / Goto
	 Shift + Play /
	 Shift + Back / Return
	 Shift + Yellow / YouTube /

