




































Original	Replacement
	Power
	Vol +
	Vol -
	Mute
	Right
	Left
	Up
	4
	Down
	3
	6
	1
	Red
	Green
	Yellow
	Shift + Power
	AV

Original	Replacement
	Vol+ Tv
	Vol- Tv
	CH+ Tv
	CH- Tv
	LG Tv
	Bluetooth
	Optical
	Port.In
	Shift + Vol +
	Shift + Vol -
	Ch +
	Ch -
	TV/R
	Smart
	Media
	Guide

