







































































































Original		Replacement		Original		Replacement	
	Power		Power		9		9
	CH.List		List		0		0
	Tv/Radio		TV/R		Info		Info
	FAV		Pre Ch		Recall		Back
	Sleep		Sleep		Freeze		Pause
	Input		AV		Guide		Guide
	Sound		Shift + Dual		I/II/Audio Lang		Dual
	Picture		Shift + Format		Vol+		Vol +
	Aspect		3D		Vol-		Vol -
	1		1		Mute		Mute
	2		2		Prog+		Ch +
	3		3		Prog/Page-		Ch -
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok





Original		Replacement		Original		Replacement	
	Menu		Menu				
	Exit		Exit				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Index		Shift + Info				
	Hold		Options				
	Text		Text				
	Size		Format				
	Subtitle		Subt				
	Mix		Media				
	Reveal		Smart				
	Cancel		Eject				
	Time		Shift + AV				
	Subpage		D. Menu				

